

MODEL 300	<b>SATx PROGRAMMING PARAMETERS</b>		06/08/13 v1.41
Command	Allowable Entry	Description	Parameter used
-----	-----	<b>HANDSET MUST BE ON-HOOK TO PROG.</b>	-----
D0_	1 > 4	NUMBER OF DIGITS IN STATION ID	1,2,3,7,8
D1_	0 > 9	MODE 0-BAT, 1-SATD, 2-RES, 3-SATS, 4-RES, 5-NAT, 6-NST, 7-RES, 8-NSAT, 9-RES	1 > 9
D2 _ _ _ _	0 > 9	STATION ID - DEPENDS ON # OF DIGITS	1,2,3,7,8
D3 _ _ _	0 > 9 Max=10	GROUP CODE - TERMINATE WITH # TO ERASE ENTIRE GROUP, ENTER D3 #####	1,2,7,8
D4 _ _	0 > 99	NUMBER OF STATION ALERT RINGS	1,2,3,7,8
D5 _ _	0 > 99	ALERT CONTINUOUS RING (SECS)	1,2,5,7,8
D6 _	0,1	PRIVACY 0=OFF (SPK ON) 1=ON (SPK OFF)	1>9
D7 _ _ _	00 > 999	PROGRAMMING PASSWORD (3 DIGIT)	1,2,3,7,8
# _ _ _	CALL OKPHONE FOR #	UNLOCK PROGRAMMING PARAMETER	not published
<b>D8 _ _</b>	<b>xx</b>	<b>SAT ALERT/LAMP &amp; ENABLE LEGACY</b>	<b>1,2,7,8</b>
		TENS DIGIT - SPK ON AFTER ALERT, AC-GRP-IND	
		ONES DIGIT - ENABLE FEATURE, CMD-GRP-KEYS	
	EX. 63	6 = ALL CALL = YES, GRP=YES, IND=NO	
		3 = CMD=NO, GRP=YES, KEYS=YES	
	8x	8 = LAMP/SPK ON TILL HANDSET OFFHOOK, THEN LAMP-ON, SPK-OFF TILL TERMINAL RCV "A#" THEN LAMP-OFF & SPK-OFF	
D9_	0	Enable DTMF/SS4 Serial Datalog	1,2,3,7,8
	1	Disable DTMF/SS4 Serial Datalog	1,2,3,7,8
<b>DAx _ _ _</b>	<b>0&gt; 999</b>	<b>MISC. SETUP PARAMETER ENTRIES</b>	<b>1,2,3,7,8</b>
DA1 _ _ _	000 or 001	ALL CALL ENABLED (0=OFF & 1=ON)	1,2,7,8
DA2 _ _ _	000 or 001	RINGBACK CONF TONES (0=OFF & 1=ON)	1,2,3,7,8
DA3 _ _ _	000 or 001	CONFIRMATION TONES (0=OFF & 1=ON)	1,2,3,7,8
<b>DB x _ _ _ _</b>	<b>Axxx,0&gt;9999</b>	<b>STATION ID ALERT # (TOTAL DIGITS=D0x)</b>	<b>1,2,3,7,8</b>
DB0 _ _ _ _		SECOND ALERT #	1,2,3,7,8
DB1 _ _ _ _		THIRD ALERT #	1,2,3,7,8
		TO DISABLE ENTER #####	
<b>DD</b>		<b>SETUP PARAMETERS - SENT TO SERIAL OUT</b>	<b>1,2,3,7,8</b>
C0_	0	Enable Speaker (RX handsfree) (temporary)	1,2,3,7,8
C1_	1	Disable Speaker (RX Handsfree) (temporary)	1,2,3,7,8
^		TELEPHONE WARM RESET (EXIT PROGRAMMING)	1,2,3,7,8