

SATx PROGRAMMING PARAMETERS			10/06/11 v1.35
Command	Allowable Entry	Description	Parameter used
-----	-----	HANDSET MUST BE ON-HOOK TO PROG.	-----
D0_	1 > 4	NUMBER OF DIGITS IN STATION ID	1,2,3,7,8
D1_	0 > 9	MODE 0-BAT, 1-SATD, 2-RES, 3-SATS, 4-RES, 5-NAT, 6-NST, 7-RES, 8-NSAT, 9-RES	1 > 9
D2 ____	0 > 9	STATION ID - DEPENDS ON # OF DIGITS	1,2,3,7,8
D3 ____	0 > 9 Max=10	GROUP CODE - TERMINATE WITH # TO ERASE ENTIRE GROUP, ENTER D3 #####	1,2,7,8
D4 __	0 > 99	NUMBER OF STATION ALERT RINGS	1,2,3,7,8
D5 __	0 > 99	ALERT CONTINUOUS RING (SECS)	1,2,5,7,8
D6 _	0,1	PRIVACY 0=OFF (SPK ON) 1=ON (SPK OFF)	1>9
D7 ____	00 > 999	PROGRAMMING PASSWORD (3 DIGIT)	1,2,3,7,8
# ____	CALL OKPHONE FOR #	UNLOCK PROGRAMMING PARAMETER	not published
D8 __	xx	SAT ALERT/LAMP & ENABLE LEGACY	1,2,7,8
		TENS DIGIT - SPK ON AFTER ALERT, AC-GRP-IND	
		ONES DIGIT - ENABLE FEATURE, CMD-GRP-KEYS	
	EX. 63	6 = ALL CALL = YES, GRP=YES, IND=NO	
		3 = CMD=NO, GRP=YES, KEYS=YES	
	8x	8 = LAMP/SPK ON TILL HANDSET OFFHOOK, THEN LAMP-ON, SPK-OFF TILL TERMINAL RCV "A#" THEN LAMP-OFF & SPK-OFF	
D9_	0	Enable DTMF/SS4 Serial Datalog	1,2,3,7,8
	1	Disable DTMF/SS4 Serial Datalog	1,2,3,7,8
DAx ____	0 > 999	MISC. SETUP PARAMETER ENTRIES	1,2,3,7,8
DA0 ____	000	RX - TX GAIN (0 = RX=-8dBm/TX=-8dBm)	1,2,3,7,8
	001	RX - TX GAIN (1 = RX=-4dBm/TX=0dBm)	1,2,3,7,8
DA1 ____	000 or 001	ALL CALL ENABLED (0=OFF & 1=ON)	1,2,7,8
DA2 ____	000 or 001	RINGBACK CONF TONES (0=OFF & 1=ON)	1,2,3,7,8
DA3 ____	000 or 001	CONFIRMATION TONES (0=OFF & 1=ON)	1,2,3,7,8
DA4 ____	000 > 128	MINIMUM SPK VOLUME ADJ. (000=LO, 128=HI)	1,2,3,7,8
DA5 ____	000 > 128	TX OUTPUT LEVEL ADJ. (dBm)	1,2,3,7,8
	DA0 000	(001=-43, 005=-30, 015=-20, 052=-10, 128=-2)	
	DA0 001	(000=-16, 026=-10, 039=-8, 052=-6, 104=-2, 128=0)	
DB x ____	Axxx,0>9999	STATION ID ALERT # (TOTAL DIGITS=D0x)	1,2,3,7,8
DB0 ____		SECOND ALERT # (TO DISABLE ENTER #####)	1,2,3,7,8
DB1 ____		THIRD ALERT # (TO DISABLE ENTER #####)	1,2,3,7,8
D*0stxxx	stxxx	FIPS CODE - st = STATE, xxx=county	1,2,5,6,8
DD		SETUP PARAMETERS - SENT TO SERIAL OUT	1,2,3,7,8
C1_	0	Enable Speaker (RX handsfree) (temporary)	1,2,3,7,8
C1_	1	Disable Speaker (RX Handsfree) (temporary)	1,2,3,7,8
^		(PC SERIAL) TEL. WARM RESET (EXIT PROG)	1,2,3,7,8
*#	HOLD > 2 SECS	(TEL KPAD) TEL. WARM RESET (EXIT PROG)	1,2,3,7,8